

02-40 GEAR TRAIN ASSEMBLY

Key No.	Part Number	Description	Qty.	Remarks
A1	570157	Lay Shaft Sub Assembly	1	
A2	570158	Main Shaft Sub Assembly	1	
1	570205	Main Shaft	1	
2	550008	Main Shaft 2nd Gear	1	
3	550023	Washer, Thrust	2	
4	550010	Main Shaft 4th Gear	1	
5	550024	Circlip	1	
6	550012	Main Shaft 3rd Gear	1	
7	570204	Main Shaft 1st Gear	1	
8	550216	Lay Shaft	1	
9	550023	Washer, Thrust	1	
10	550009	Lay Shaft 2nd Gear	1	
11	550007	Lay Shaft High Gear	1	
12	550011	Lay Shaft 3rd Gear	1	
13	570202	Lay Shaft 1st Gear Assembly	1	
14	550090	Selector Fork	1	
15	550081	Selector Fork	1	
16	550091	Selector Fork	1	
17	550078	Selector Fork Shaft	1	
18	550141	Circlip	1	
19	570216	Cam Plate Assembly	1	
20	550075	Roller	4	